



Notes:

* See the "Installation" section, "Wiring" sub-section of the manual for notes regarding proper grounding.

The Serial input, and Audio Output are reserved for future growth. Leave these unconnected at this time.

The Serial Output should be left unconnected if not used. Do not wire to these inputs. They are reserved for future growth.

Figure 5a -- Connector A Wiring for Model 4000/6000/9000